


The leading centrifuge

for process applications-A-series






The ANDRITZ Decanter - A-series

The optimum process centrifuge for almost any application

With more than 15,000 machines installed, ANDRITZ is one of the leading suppliers of decanter centrifuges. The comprehensive product portfolio also comprises the product range acquired from Humboldt and Bird Machine. ANDRITZ can offer an optimum machine for almost all process applications (A-series) up to 1.4 m diameter. The robust design of the machines allows a service life of several decades.





Optimum feed chamber design



Feed chamber option Patented accelerator XL Plus

Optimized design single, double or triple lead conveyor






Your benefit

- optimized scroll geometry for numerous applications
- process experience from a large number of reference installations
- in stainless steel, Hastelloy, titanium or nickel
- optimized wear protection for abrasive media
- solid and robust design for demanding operating conditions
- also for gas-tight and pressurized operation
- heavy duty gearbox up to 120,000 Nm
- OEM service available worldwide

for maximum production

Decanter centrifuges




Customized design

Drive


■ direct with VFD



■ with fluid couplung



■ with special drive for CIP



Housing

atmospheric/ seal up to 0.01 bar



gas-tight up to 0.5 bar



pressure-tight




Wear protection






Solid-bowl decanter centrifuge - Type A

The solid-bowl decanter is the basic, standard machine to separate solid and liquids. Typical applications are all kinds of plastic material (PVC, HDPE, PTA), but also for CaCO₂, kaolin, drilling mud, tunnel drilling, and various residues.




3-phase decanter

This machine is used when not only a solid is to be separated from the liquid, but when the liquid contains two phases of differing densities. Besides treatment of oil and fats, such machines are used to recover oil from tank cleaning operation (slop oil).



Screen-bowl decanter centrifuge - Type AS

Screen-bowl decanters discharge crystalline solids over the conical section. These are transported along a cylindrical screen section, where the solids are further dewatered - combining the steps of sedimentation and filtration in one machine. Where advantageous, the solids can be washed on the screen. The most common applications are potash, fine coal and BPA.




CENSORTM solids-sorting centrifuge - Type AC

The CENSORTM centrifuge is used to selectively separate plastic fractions of differing densities. During the process, the product is washed using a minimal quantity of water. The resulting recycled products are then available for high-quality reuse.



Basket centrifuges



Screen scroll centrifuge - Type AH

The screen scroll centrifuge is used to separate (and possibly wash) medium coarse particles (> 0.2 mm) like salt, coal, and potash. A scroll is used to transport the solids along the screen basket.



Vibrating screen centrifuge - Type AES

The vibrating screen centrifuge is used to separate coarse particles (> 0.5 mm) like salt and coal. The transport of solids is assisted by vibrating the screen basket.

Typical applications

Plastics: PVC, HDPE, PTA, PBA,

Melamine

Anorganic chemicals: Potash,

salts, gypsum, soda

Ores and minerals: Coal, CaCO,

kaolin, uranium, copper **Residues:** Drilling mud, tunnel

drilling, slop oil, tailings

NORTH AMERICA

ANDRITZ SEPARATION Inc.

Phone: +1 (817) 465 5611 Fax: +1 (817) 468 3961 separation.us@andritz.com

SOUTH AMERICA

ANDRITZ SEPARATION Ltda.

Phone: +55 (47) 3387 9100 Fax: +55 (47) 3387 9103 separation.br@andritz.com

EUROPE

ANDRITZ AG

Phone: +43 (316) 6902 2318 Fax: +43 (316) 6902 92318 separation@andritz.com

ASIA

ANDRITZ Singapore Pte. Ltd.

Phone: +65 (6512) 1800 Fax: +65 (6863) 4482 separation.sg@andritz.com

CHINA

ANDRITZ (China) Ltd.

Phone: +86 (757) 6663 3419 Fax: +86 (757) 6663 3448 separation.cn@andritz.com

AUSTRALIA

ANDRITZ Pty. Ltd.

Phone: +61 (2) 4914 4000 Fax: +61 (2) 4955 3788 separation.au@andritz.com

AFRICA

ANDRITZ Delkor (Pty) Ltd.

Phone: +27 11 466 2361 Fax: +27 86 636 2122 separation.za@andritz.com

www.andritz.com